

Cleaning Instruction


Cleaning operation (please refer to the Installation Manual for further details,p.9)

Cleaning Operation	When alert is shown	Every week / tank refilled	As required
Capsule drawer	Yes	Yes	
Capsule lid		Yes	
Water tank		Yes	
Steam / Hot water arm		Yes	
Brewing chamber Rinsing cycle			Yes

Capsule Drawer (message 'Empty Grounds' may appear on screen)

- Lift the cup holder, remove and empty the drawer
- Wash the drawer in cold water and soap, then rinse in cold water. No dishwasher
- Insert the drawer as the screen says 'Insert cof.groun.drawer'


Steam / Hot water Arm

- Wipe the milk off the Steam arm with a wet cloth
- Press  once and let steam run to expel old mik. Press again to stop.
- Pull the stainless steel tip off the arm and rinse it in cold water until clean



Brewing Chamber Rinsing Cycle

LB2312 is programmed to ask for rinsing cycle every day.

- Press  to proceed. A couple ounces or hot water will be dispensed through the front coffee spouts.

Body and panels

- Use a wet cloth to clean out the exterior (do not use detergents), including:
 - o Front holders and cup warmer
 - o Screen and keypads, better with machine off to not accidentally activate steam.
 - o Water tank
 - o Capsule lid